











GRIN 90

CONTINUOUS GUARD RAIL




GRIN 90/150

ASSEMBLY INSTRUCTIONS



WARNING
The distance of installation depends on speed and weight of vehicle



GRIN 90/150

ASSEMBLY INSTRUCTIONS

